7. ERROR INDICATION:

If cannot solved as per the above methods, contact the professional personnel.

source is normal (380V)			
Power board troubleshooting Check if the correct of the power	Reverse rotation not correct	REO	ERR
Execute the user setup correctly	User setup not correct	USR	ERR
Execute the factory setup correctly	Factory setup incorrect	FAC	ERR
Restart again	Stop incorrect, press start key or lift the hood	OFF	ERR
Check the motor and belt and also if the display of the photocell plate is normal	Rotation speed not enough Photocell coupler cannot collect the signal	SP	ERR
Lower down the hood	Hood not lower down	OPN	ERR
solution	Troubleshooting reason	У	Display

If cannot solved as per the above methods, contact the professional personnel.